



ATOM 35 CONTENEUR PRINCIPAL  
MAIN CONTAINER

**Configuration:** Conteneur principal plié avec extracteur à ressort.  
**Origine de l'incident:** Lors de l'action d'ouverture du conteneur principal, l'arrimage de la bouclette sur sa patte de fixation peut générer un blocage et un retard de jaillissement de l'extracteur.  
**Remède à apporter:** Fixer la bouclette de fermeture sur le rabat inférieur du principal selon les schémas ci-dessous. Inverser l'ordre de fermeture des rabats latéraux:  
**Fermer dans l'ordre:** 1) Rabat inférieur avec bouclette, 2) rabat latéral droit, 3) rabat latéral gauche, 4) rabat supérieur.

**Configuration:** Main container packed with spring pilot chute.  
**Incident Origin:** After pulling out the main ripcord, the closing loop's of the main container may delay the exit of the pilot chute.

**Modification:** Install the main closing loop on the lower flap of the main container as shown on pict N°1,2,3  
 Invert the flaps closure's order: 1) Lower flap (locking loop) 2) right flap, 3) left flap, 4) upper flap.






**Equipement nécessaire:**  
 - 2 Rondelles inox 5 x 16 \* réf: 9001471000  
 - 1 Bouclette de fermeture réf: 2007084500

**Equipment required:**  
 - 2 stainless steel washers 5 x 16 \* réf: 9001471000  
 - 1 main closing loop réf: 2007084500

Passer la bouclette selon le dessin N°1 en prenant la précaution de mettre la partie lisse de chaque rondelle à l'extérieur et la partie pouvant comporter la bavure de découpage vers l'œillet.  
 - Ajuster la longueur utile de la bouclette à une longueur d'environ 4 cm.  
 - Bloquer l'ensemble selon le dessin N°2  
 - La patte d'attache d'origine n'est plus utilisée  
 \* La bouclette d'origine est livrée avec 1 rondelle.  
 Le montage nécessite une rondelle supplémentaire

- Install the locking loop as shown in drawing N°1 taking good care of positioning the sliding side of each washer outside the grommets.  
 - Adjust the length of the loop to about 4 cm.  
 - Pull the two parts of the loop (drawing N°2)  
 - The original attachment loop is not used anymore  
 \* The original loop is delivered with 1 washer.  
 The assembling requires another one.

Cheminement de la bouclette  
Routing of the locking loop



STAMP