

# STRONG ENTERPRISES

11236 SATELLITE BLVD.

ORLANDO, FL 32821

(407) 859-9317

FAX (407) 850-6978

THE PARACHUTE COMPANY WITH IMAGINATION

## Supplemental Packing Instructions for the Mini/Student Hawk Mini Hawk Part # 114750, Student Hawk Part # 114765/68

The following instructions illustrate the proper installation of the reserve static line lanyard onto the Mini Hawk and Student Hawk harness and containers.

Located on the left main riser is a Type 1 loop used to secure the static line lanyard to the riser (illustration 1).

Secure the lanyard to the riser using a larks head knot. (illustration 2).

Mate the hook velcro on the lanyard to the pile velcro that runs along the container yoke (shoulder area) (illustration 3).

Install the #5 rapide link around BOTH ripcord cables BETWEEN the ripcord cable housing and the Type IV webbing that runs horizontally across the middle of the top reserve closing flap (illustration 4).




Illustration 1




Illustration 2




Illustration 3




Illustration 4

